

AUTO DRAUGHT

Pour Smarter.



To access settings, press bottom right of screen (hidden button).



Dispense

Open Tap - Tap will open once pressed.

Close Tap - Tap will close once pressed.



Pour Start Height

- The distance the nozzle is from base of cup when pouring starts.



Nozzle Clearance

- The distance of nozzle from the top of drink as it pours.



Stop Below Brim

- The distance of the top of drink to the top of cup, when pouring stops.



Foam Duration

- The time the valve is in the foam position at the start of the pour.



- When unlocked, all values can be edited by bartenders.



Glasses



Fixed Glasses - On/Off

- When turned off, virtually any cup will work - check dispense settings!
- When turned on, up to 5 different sized glasses can be programmed.
- Select No. - Place cup on platform, height and weight will be recorded.
- Only cups programmed will work.



- When unlocked, fixed glasses can be edited by bartenders.



Sensors



Gross Weight

- Shows a live value reading of the weight on the cup platform.
- Should be 0g without cup.



Zero Weight

- Press to zero the weight the when reading is not 0g without cup.



Vertical Distance

- Click to check if vertical sensor is working - live value shown.



Horizontal Distance

- Click to check if horizontal sensor is working - live value shown.



About

Shows device information - device ID etc.



Restart Device

- Press to restart device.



Help

Shows QR code for help - use mobile phone.

More Help?

